lkegami

BROADCAST HD MONITORS LINEUP





HLM-2460WA



HLM-1860WR



HLM-960WR



HLM-2460WA

24-inch Full HD Multi-format LCD Monitor

HDMI[™] HDR (Option)

Building on the renowned features and performance of its predecessor, the HLM-2460WA reproduces more accurate dynamics of the source images thanks to a newly-developed LCD panel with an impressive 1800:1 contrast ratio. Seamless tally integration via Ethernet is made possible by the support of the TSL V5.0 protocol. The HLM-2460WA fits into various broadcast workflow applications, including editing suites where a computer-friendly WUXGA display resolution is preferred, as well as monitor walls, among others.

Specifications					
24-inch WUXGA	1920 x 1200 pixel	178°(H/V)	Contrast 1,800:1	400 nits	
Input/Output					
3G/HD-SDI	HDMI (HDCP)	CVBS	Embedded Audio	Analogue Audio I/O	
Features					
UMD IMD	VITC/LTC	WFM	Vectorscope	сс	Split Screen
P-in-P	Zoom Display	HDR *Option	Auto Calibration *Option	TSL Tally V5.0	
Size, Weight					
W 562 x H 398 x D 86 mm (22.1 x 15.7 x 3.4 inches)	9RU	9.1 kg (20.1 lbs)			



HLM-1860WR

18.5-inch Full HD Multi-format LCD Monitor

HDM (Option)

The HLM-1860WR features a larger 18.5-inch LCD panel within the same 19-inch rack-width 7RU chassis as its predecessor. Seamless tally integration via Ethernet is made possible by the support of the TSL V5.0 protocol. The bright LCD panel boasting 500 nits reproduces clear images even in environments with predominant ambient light. The HLM-1860WR fits into outdoor as well as indoor monitoring applications.

Specifications					
18.5-inch Full HD	1920 x 1080 pixel	178°(H/V)	Contrast 1,000:1	500 nits	
lagut/Outgut					
Input/Output					
3G/HD-SDI	HDMI (HDCP)	CVBS	Embedded Audio	Analogue Audio I/O	
Features					
UMD IMD	VITC/LTC	WFM	Vectorscope	СС	Split Screen
P-in-P	Zoom Display	HDR *Option	Auto Calibration *Option	TSL Tally V5.0	
Size, Weight					
W 440 x H 301 x D 80 mm (17.3 x 12.2 x 3.2 inches)	7RU	5.9 kg (13.01 lbs)			

HLM-960WR

9-inch Full HD Multi-format LCD Monitor

The HLM-960WR is a highly compact multi-format LCD monitor with a 9-inch Full HD 1920 x 1080 pixel 400 nits 8-bit resolution LCD panel. This model offers very narrow front-to-back dimensions, light weight and low power consumption. Multi-format SDI, 3G-SDI, HDMI and VBS inputs are provided as standard. Battery operation is available using an optional battery bracket.



Specifications 9-inch Full HD 1920 x 1080 pixel 178°(H/V) Contrast 700:1 400 nits Input/Output HDMI (HDCP) CVBS Embedded Audio 3G/HD-SDI Analogue Audio I/O Features UMD IMD VITC/LTC WFM СС Split Screen Vectorscope HDR Auto Calibration P-in-P Zoom Display TSL Tally V5.0 *Option Option Size, Weight 1.7 kg (3.75 lbs) W 222.4 x H 173 x D 69.5 mm 4RU (8.8 x 6.8 x 2.8 inches)

HLM 60 series Connector Panel



Common features for HLM 60 series

Loaded with Information Display

The HLM 60 series monitors supports dynamic and static UMD in addition to the features shown below.



User Defined Markers

A program production aid allowing up to 12 lines or boxes to be displayed. These can be drawn easily using a USB mouse.



10 different Scene files for User Markers

It is possible to create User Marker displays, up to 10 scenes. Each scene can be set in real time by users with the "FUNCTION" switch on the front panel.



Remote control with wireless mouse

A USB wireless mouse can be used to remotely control monitors installed at high locations.



2 Split-Screen Display

Display mode can be selected from side by side, picture in picture, horizontal wipe, and vertical wipe. This function is convenient for adjusting colors and position of multiple cameras. Two live signals also can be displayed



Automatic Calibration (Optional)

Optional AWC software ensures consistent and accurate color reproduction over time. By acquiring real-time measurement data via a colorimeter, Windows-based software automatically aligns the R/G/B gain to exhibit the correct white balance.



Zoom Display Function

This function is to enable 2X/4X magnification without scaling of the image. It is useful to confirm errors in the signal, such as dead pixels of a CCD camera and to check in the detailed sections of the picture.



MIX TEST SIGNAL Function

It is possible to mix the live picture with a reference TEST signal generated by the monitor. This provides a good reference for black and white levels which could otherwise be difficult to confirm with certainty due to the front panel adjustment of Contrast and Brightness. Regarding the peak level of the input signal, users can confirm an overload with the Alarm LED (OVER RANGE) on the Front panel.

*HDTV only



High Dynamic Range (Option)

The 60 series monitors support HDR (High Dynamic Range) EOTF tables of HLG1, HLG2, and S-Log3 as an option in addition to conventional gamma.



SDR Picture

HDR Picture

Specifications







		HLM-2460WA HLM-1860WR		HLM-960WR			
Display	Panel						
LCD Type		IPS equivalent, TFT-LCD (normally black)	IPS equivalent, TFT-LCD (normally black)	a-Si TFT Active Matrix			
Resolution		1920 x 1200	1920 x 1080	1920 x 1080			
Display Si	ize	24-inch	18.5-inch	9-inch			
Brightnes	S	400 nits	500 nits	400 nits			
Contrast F	Ratio (typ.)	1800:1	1000:1	700:1			
Display Co	olor	1.07 billion colors	16.77 million colors	16.77 million colors			
Viewing A	ngle	178°	178°	178°			
Ratings	;						
Power Requirement		AC: 100 to 120 / 200 to 240 V AC	AC: 100 to 120 / 200 to 240 V AC DC: 12 V DC (10.5 to 18 V DC)	AC: 100 to 120 / 200 to 240 V AC DC: 12 V DC (10.5 to 18 V DC)			
Power Co	nsumption	49 W AC: 47 W		AC: 28 W			
			DC: 42 W/3.5 A	DC: 27 W/2.4 A			
Dimensions		W 562 x H 398 x D 86 mm	W 440 x H 301 x D 80 mm	W 222.4 x H 173 x D 69.5 mm			
		(W 22.1 x H 15.7 x D 3.4 inches)	(W 17.3 x H 11.9 x D 3.2 inches)	(W 8.8 x H 6.8 x D 2.8 inches)			
Rack-mountable Space		9RU (Excluding Desktop Stand)	7RU	4RU			
Weight		Approx. 9.1 kg (20.06 lbs)Approx. 5.9 kg (13.01 lbs)(Excluding Desktop Stand)		Approx. 1.7 kg (3.75 lbs)			
Video							
Input /	3G/HD/SD-SDI	2-input/2-output (Active Through) or 4-input					
Output VBS		1-input/1-output (Loop Through)					
	HDMI 1-input (HDCP)		1-input (HDCP)				
Audio							
Input Embedded Audio		SDI & HDMI					
		Stereo Mini Jack					
Output	Embedded Audio						
	Speaker	1 W + 1 W (Mono)		1 W (Mono)			
	Headphones	Stereo Mini Jack					
Control							
Ethernet		Remote Control & Tally/UMD (TSL V5.0)					
RS-485			Tally/UMD (TSL V3.1)				
GPIO		Parallel Remote Connector					

Dimensions (unit: mm)

HLM-2460WA



HLM-1860WR



HLM-960WR



Options

Compatibility Chart

	Model	Description	HLM-2460WA	HLM-1860WR	HLM-960WR	Remarks
Rackmount Adaptor	RS-2450T	Rackmount Adaptor				Fixed Tilt Angle Type (Made to order item)
	RS-1860	Rackmount Adaptor				Fixed type
	TLB-186	Tilt Bracket for RS-1860				Fixed angle type
	DR-960	Dual Rackmount Adaptor				4RU
	DR-960T	Dual Rackmount Adaptor (Tilt type)				5RU (Made to order item) Tilt: Up 8 / Down 20 degree
	BP-960	Blank Panel for DR-960				
	BP-960T	Blank Panel for DR-960T				(Made to order item)
	STD-240T	Stand with Tilt Mechanism				Tilt: Up 45 / Down 8 degree (Made to order item)
	STD-1760	Monitor Stand				
	STD-1760T	Stand with Tilt Mechanism				Tilt: Up 15 / Down 15 degree
Stand	STD-1722M	VESA Arm Stand				· · · ·
	STD-960	Monitor Stand				
	STD-960T	Stand with Tilt Mechanism				Tilt: Up 10 / Down 10 degree
Tripod Mount Plate	AT-900	Tripod Mount Plate				1/4 & 3/8 inch hole plate
Handle	GR-1770	Handle				
	GR-904	Handle				
LCD Protection Cover	PP-1860	LCD Protection Cover				Anti-Refelection Coating
	PP-960	LCD Protection Cover				Anti-Refelection Coating
Battery Bracket	BB-1750A	Battery Bracket (Anton Bauer Type)				(Made to order item)
	BB-1750V	Battery Bracket (V-Mount Type)				(Made to order item)
	BB-904A	Battery Bracket (Anton Bauer Type)				with handle
	BB-904V	Battery Bracket (V-Mount Type)				with handle
Hood	MH-1860	Hood				(Made to order item)
	MH-904	Collapsible Hood				
Carrying Case	CC-2460A	Hard Carrying Case				(Made to order item)
	CC-1860	Hard Carrying Case				(Made to order item)
	CC-960	Hard Carrying Case				(Made to order item)
	IS-016	Soft Carrying Case				
Remote Controller	RCT-30A	Infrared Remote Controller				
	SRC-400	Serial Remote Controller				(Made to order item)

Rackmount adaptor

RS-1860

ount Adaptor



Dual Rackmount Adaptor



Brank Panel for DR-960





Battery Bracket (Anton Bauer Type)

STD-960T

Tilt Stand

BB-1750V



Handle



Stand

Rack



STD-1760T

Tilt Stand

Hood

Stand

Hood





Collapsible Hood

Design and specifications are subject to change without notice.



STD-1722M

VESA Arm Stand



CC-1860 Hard carrying Case

STD-960

Stand



PP-1860

LCD Protection Cover

GR-1770



BB-904A

Battery Bracket (Anton Bauer Type)





GR-904

Handle

RCT-30A ed Remote Control Infra

HDMI is a registered trademark of HDMI Licensing LLC.



■ Headquarters : 1 Tampines Central 5, #06-04 CPF Tampines Building, Singapore 529508 ···· TEL.+65-6260-8820 / FAX.+65-6260-8896

