

Ikegami

7-inch native HD LCD Viewfinder VFL-P700A



VFL-P700A is a 7-inch native HD LCD viewfinder. It is compatible with Unicam HD series cameras such as the HDK-73 and HDK-99. With the high performance LCD panel, the VFL-P700A is the ideal viewfinder for both indoor and outdoor operations.

High Performance LCD Panel

The native HD 1920 x 1080 screen provides easy and accurate focusing. In combination with the wide viewing angle and the quick response, the VFL-P700A enables optimal operability.

Waveform Monitor/Vectorscope

The VFL-P700A viewfinder incorporates a variety of test-related features including a waveform monitor, vectorscope and audio level meter.

External Inputs

Supporting HDMI and 3G/HD-SDI input, the VFL-P700A can be also used as a field monitor.

Specifications/Ratings

LCD Panel	
Resolution	1920 (H) x 1080 (V) dots
Screen Size	151 (H) x 85 (V) mm
Viewing Angle	up & down, left & right: 170°
General	
Input Voltage	10 to 16V DC
Power Consumption	Approx. 12W
Operating Temperature	0°C to +40°C
Operating Humidity	30% to 85% (no condensation)
Dimensions	W232 x H146 x D47 mm (body only)
Weight	Approx. 1.2 kg (body only)
Supported Products	Unicam HD Series HDK-99, HDK-73, HDK-79GX * Contact us for other supported models

Specifications		
Input Signal	3G/HD-SDI	1x BNC
	SDI RET	1x BNC
	HDMI	1 ch
	CAMERA	1x 12-pin
	RET Control	1x 8-pin
	DC Power	1x XLR 4-pin
	TALLY 1	1x BNC G (2-4V) / R (4.1-5V) / OFF (0-2V)
	TALLY 2	1x BNC R (ON/Short to GND) / OFF (Open)
Output Signal	3G/HD-SDI	1x BNC (Active Loop Through)
	HDMI	1 ch (Active Loop Through)
Tally Indicators		Front x2 (G/R), Rear x1 (R)

Design and specifications are subject to change without notice.



Ikegami Tsushinki Co., Ltd.

■ URL: www.ikegami.co.jp/en/

■ Headquarters : 5-6-16 Ikegami, Ohta-ku, Tokyo 146-8567, Japan TEL.+81-(0)3-5700-1111
 ■ Beijing Office : Tower A Room No.823-824 Jia Tai International Mansion No.41
 East Fourth Ring Road,Chaoyang District,Beijing ,China TEL.+86-10-8571-0350

U483B246-SELF

Ikegami Electronics (U.S.A.), INC.

■ URL: www.ikegami.com

■ Headquarters : 300 Route 17 South, Mahwah, NJ 07430 USA TEL.+1-201-368-9171



Ikegami Electronics (Europe) GmbH

■ URL: www.ikegami.de

■ Headquarters : Ikegami Strasse 1, D-41460 Neuss, Germany TEL.+49-(0)2131-1230

Ikegami Electronics Asia Pacific Pte.Ltd.

■ URL: sg.ikegami.co.jp

■ Headquarters : 1 Tampines Central 5, #06-04 CPF Tampines Building, Singapore 529508 TEL.+65-6260-8820